
S9060
Ignition light switch
Off
On
Off
On
Off
Off
On
Park
X9060
F1
F3
Fuse box
F9200
A9500
Motronic control unit
A9001
Instrument cluster
H9190
ABS indicator lamp
P9210
Speedometer
P9002
Revolution counter
X9001
X9028
X9450
X9431
X9643
X9409
X9390
X9440
X9650
X9402
W9690
Battery positive
X9230
Battery
G9230
Battery ground
X9231
X9803
Double relais base
Motronic/Load relief relay
K9803
Motronic relay
K9110
X9590
Diagnostic connector
Fan
M9140
Valve 1
Y9601
Timing valve
Y9572
Oxygen sensor
B9690
Throttle actuator
M9576
Fuel pump
M9100
Ignition coil
T9010
Spark plug
R9611
X9974
Plug connection option 2